



INSTRUCTIONS FOR WL 1468 "SNAP TOGETHER" GRILLE CUTTER

The WL 1468 consists of 2 cutters:

1. a straight cutter
2. an angular cutter

With the straight cutter, fence off, using a mitre. Where your grilles will cross, put one on the bottom ½ way up, and cut the other ½ way down from the top.



With the angular cutter, cut the sides of both pieces, leaving a space between the two angular cutters, a space equal to the diameter of the straight cutter.



The two pieces will now snap together. These cutters (part #WL 1468) do the exact cut of the \$27,000. machine normally used for this operation.